



MODEL
BL36200

HIKOKI

BACK PACK POWER SUPPLY

Item No.	Code No.	Description	No. Used	Remarks
1	335718	LARGE-CAPACITY BATTERY (FOR BL36200) USA	1	FOR USA,CAN
1A	335719	LARGE-CAPACITY BATTERY (FOR BL36200) EUR	1	
2	375179	CAUTION PLATE	1	
3		NAME PLATE	1	
4		BRAND LABEL	1	
5	375176	SWITCH HOLDER (A)	1	
6	375177	SWITCH HOLDER (B)	1	
7	375178	SWITCH PCB	1	
8	375180	SCREW D3	4	
		STANDARD ACCESSORIES		
501	335716	SCREW SET M5	1	
*502	373704	BATTERY ADAPTER	1	MODEL CG36DA,CG36DTA,CH3656DA,CS3630DA,
*502	373704	BATTERY ADAPTER	1	RB36DA
503	335123	CARRY BAND	1	
504		CHARGER (MODEL UC 36YRSL)	1	

* ALTERNATIVE PARTS