


B34

CG47EJ(T)

Serial No.

B34-01


CG47EJ(T) CYLINDER/PISTON/CRANK SHAFT



REF. NUMBER	PARTS NUMBER	DESCRIPTION	QTY	SERIAL NUMBER
006	668-747	SPARK PLUG CAP ASSY	1	
007	668-833	SPARK PLUG RUBBER COVER	1	
008	668-508	SPARK PLUG BPMR6A	1	
011	668-547	CYLINDER SET	1	
012	668-458	HEX HOLE BOLT M5X18/S	4	
014	668-573	CYLINDER GASKET	1	
015	668-612	PISTON RING	2	
016	668-588	PISTON SET	1	
017	668-601	PISTON PIN 10X35	1	
018	668-602	PISTON PIN CIRCLIP	2	
020	668-599	PISTON PIN COLLAR	2	
021	668-619	CRANK SHAFT COMP.	1	
022	669-560	NEEDLE BEARING, 2X8.8	1	
031	668-645	WOOD-RUFF KEY 3X13X5	1	

B34-02


CG47EJ(T) CRANK CASE



REF. NUMBER	PARTS NUMBER	DESCRIPTION	Q'TY	SERIAL NUMBER
023	669-513	SMALL NUT 10	1	
026	668-655	CRANK CASE ASS'Y	1	
027	668-671	CRANK CASE GASKET	1	
028	669-563	OIL SEAL UD15257	2	
029	669-555	BALL BEARING #6202, 35MM/OD	2	
030	668-646	CRANK SHAFT WASHER 15.2X22	2	
032	668-647	CRANK SHAFT SHIM 0.20	V	
032	668-647	CRANK SHAFT SHIM 0.30	V	
036	669-508	HEX HOLE BUTTON SCREW 6X45	2	
038	668-482	HEX. SOCKET HD. BOLT (W/BUTTON) M6	2	
040	668-796	LEAD WIRE ASS'Y	1	
045	668-482	S. WASHER 6	4	
046	668-487	LOCK NUT M6	1	
047	669-404	OUTER RECEIVER	1	
051	668-737	MAGNET ROTOR COMP.	1	
052	669-518	SMALL WASHER 10	1	
054	669-513	NUT 10	1	
055	668-764	IGNITION COIL COMP.	1	
056	669-533	SCREW 5X18/S	2	
058	668-486	SMALL WASHER 5	2	
063	668-800	CORD CLAMP COMP.	1	
066	668-697	FAN CASE, VERMILION	1	
067	669-536	SCREW 6X20/S	4	
068	668-805	PRIMARY CORD GROMMET	1	
069	668-804	PRIMARY CORD GROMMET	1	

B34-03


CG47EJ(T) ENGINE-1



REF. NUMBER	PARTS NUMBER	DESCRIPTION	Q'TY	SERIAL NUMBER
027	669-222	FUEL TANK CUSHION RUBBER	2	
031	668-988	INLET MANUFOLD GASKET	1	
032	668-995	CARB. INSULATOR SET	1	
033	668-982	CARBURETOR GASKET	1	
045	669-046	CARBURETOR ASS'Y	1	
049	669-542	SCREW 5X24WS	2	
051	669-100	CHOKE LEVER	1	
052	668-526	FUEL PIPE 2.5X4X90	2	
053	669-513	SMALL NUT 10	1	
054	669-523	INNER TOOTHED WASHER 10	1	
055	669-008	PRIMING PUMP COMP.	1	
063	668-816	FUEL PIPE ASS'Y 3X5X180	1	
064	668-461	CLIP, 6.3 DIA.	1	
065	669-227	PUMP FILTER BODY ASS'Y	1	
066	669-152	FUEL TANK, VERMILION	1	
068	668-462	RETURN GROMMET	1	
070	669-171	TANK CAP D ASS'Y, ORANGE	1	
076	669-192	TANK HOLDING BAND	1	
077	669-219	CUSHION RUBBER	1	
078	669-538	SCREW 5X16/PS	2	
096	668-462	TANK CAP CHAIN	1	

B34-04


CG47EJ(T) ENGINE-2



REF. NUMBER	PARTS NUMBER	DESCRIPTION	Q'TY	SERIAL NUMBER
001	669-277	MUFFLER PROTECTOR	1	
002	669-538	SCREW 5X12/PS	1	
003	668-466	HEX. HOLE BOLT M5X12/S	1	
004	668-491	WASHER M5	1	
005	669-508	HEX. HOLE BUTTON SCREW 6X65	2	
006	668-463	WASHER 6	2	
007	669-246	MUFFLER SET, SPARE	1	
009	669-288	MUFFLER SPECIAL GASKET	1	
010	669-264	TAIL PIPE SET, SPARE	1	
011	669-532	SCREW 4X8/S	2	
014	669-274	MUFFLER GASKET	1	
016	668-724	HEAT SHIELD	1	
023	669-538	SCREW 5X18/PS	2	
025	669-220	TANK BRACKET	1	
026	669-222	FUEL TANK CUSHION RUBBER	2	
081	668-964	CLUTCH WASHER B	2	
082	668-861	CLUTCH ARM	2	
083	668-942	CLUTCH SPRING	1	
084	669-520	WAVE WASHER 10	2	
085	668-962	CLUTCH STEP BOLT	2	


B34-05

CG47EJ(T) RECOIL STARTER




REF. NUMBER	PARTS NUMBER	DESCRIPTION	Q'TY	SERIAL NUMBER
000	669-2974	RECOIL STARTER BODY AS	1	
001	669-3024	RECOIL STARTER BODY CO	1	
002	669-3000	STARTER ROPE REEL	1	
003	669-3114	RECOIL SPRING	1	
009	669-3164	STARTER ROPE	1	
012	669-3600	STARTER HANDLE CAP	1	
014	669-3234	STARTER HANDLE	1	
017	669-3634	SET SCREW	1	
019	669-3304	STARTER PAWL	1	
020	668-4684	STOP RING E-5	1	
023	669-5394	SCREW 5X25PS	2	
024	669-3344	STARTER PAWL SPRING	1	
025	669-3394	STARTER PULLEY	1	

B34-06 CG47EJ(T) AIR CLEANER



REF. NUMBER	PARTS NUMBER	DESCRIPTION	Q'TY	SERIAL NUMBER
036	669-0104	CLEANER BODY	1	
037	669-2244	COLLAR 5.8	2	
038	669-0844	BLOW OVER CHECK BOARD COMP	1	
039	669-0354	CLEANER ELEMENT	1	
041	669-0144	CLEANER COVER ASS'Y	1	
042	669-0384	COVER FIXING BOLT	1	
043	669-5354	SCREW 5X60/S	2	


CG47EJ(T) CABURETOR




REF. NUMBER	PARTS NUMBER	DESCRIPTION	Q'TY	SERIAL NUMBER
001	668-5211	SCREW	1	
002	669-1424	PUMP BODY	1	
003	669-1453	PUMP GASKET	1	
004	669-1444	PUMP DIAPHRAGM	1	
005	668-4704	INLET SCREEN	1	
017	669-0764	IDLE ADJUST SPRING	1	
018	669-0734	IDLE ADJUST SCREW	1	
022	668-5211	NEEDLE VALVE	1	
023	669-0874	VALVE SPRING	1	
024	669-0814	CONTROL LEVER	1	
025	668-5211	HINGE PIN	1	
026	668-5211	HINGE PIN SET SCREW	1	
027	669-0844	DIAPHRAGM GASKET	1	
028	669-0824	METERING DIAPHRAGM COMP.	1	
029	669-0434	AIR PURGE COMP.	1	
030	669-0864	DIAPHRAGM COVER	1	
031	669-1314	SET SCREW	4	

B34-08

CG47EJ(T) CLUTI CASE




REF. NUMBER	PARTS NUMBER	DESCRIPTION	Q'TY	SERIAL NUMBER
001	668-860	CLUTCH SHAFT COMP.	1	
002	669-529	STOP RING C-32, INNER	1	
003	669-553	BALL BEARING #6002ZZ, 32MM/OD	1	
004	668-918	WASHER	1	
005	669-528	STOP RING C-15, OUTER	1	
006	669-530	STOP RING C-45, OUTER	1	
007	668-922	CLUCH CASE	1	
008	669-190	CUSHION RUBBER	1	
009	668-966	PIPE HOLDER	1	
010	669-504	HEX. HOLE BOLT 5X10	1	
011	669-508	HEX HOLE SCREW 6X30	4	
012	669-549	HEX.HOLE BOLT 6X30/S	1	
013	668-482	S.WASHER 6	4	



REF. NUMBER	PARTS NUMBER	DESCRIPTION	Q'TY	SERIAL NUMBER
001	668-9474	DRIVE SHAFT 1542L	1	
002	668-9404	DRIVE SHAFT PIPE COMP. 1	1	
003	668-9524	BUSH ASS'Y	7	
016	668-9274	HANGER	1	
017	668-9274	LIFTING METAL ASSY	1	
018	668-9294	HANGER FIXING BRACKET	1	
019	669-5514	HEX. HOLE BOLT 5X25WS	1	
063	668-4704	HANDLE GRIP	1	
064	669-1204	HANDLE KNOB COMP.	1	
065	669-2954	MOUNTING WASHER 1.0	1	
066	669-1144	HANDLE BRACKET A	1	
067	669-1154	HANDLE BRACKET B	1	
068	669-1194	CUSHION RUBBER	1	
069	669-1174	HANDLE BRACKET C	1	
070	669-1164	HANDLE BRACKET B	1	
071	669-5514	HEX. HOLE BOLT 5X25WS	2	
072	668-9294	HIP PAD	1	
074	668-8024	CORD CLAMP	2	
075	669-1084	HANDLE LEFT ASSY	1	
084	668-7544	PROTECTION TUBE 7X790L	1	
091	669-2874	SHOULDER BELT ASSY,D3	1	
092	669-1084	RIGHT HANDLE	1	
095	669-3724	THROTTLE LEVER ASSY 19	1	
098	668-4724	SAFETY LEVER	1	
100	668-4724	RETURN SPRING	1	
101	668-4724	THROTTLE LEVER	1	
103	668-4724	BLIND PLUG	1	
106	668-4724	SCREW M4X20 (BLACK)	2	
107	668-4724	SCREW 5X30 (BLACK)	1	
108	668-4724	CONAL NUT 5	1	
110	668-7434	STOP SWITCH COMP.	1	
120	669-4004	THROTTLE WIRE	1	
125	669-3954	THROTTLE WIRE COMP.	1	

B34-10


CG47EJ(T) GEAR CASE



REF. NUMBER	PARTS NUMBER	DESCRIPTION	QTY	SERIAL NUMBER
001	668-8799	GEAR CASE ASSY 28 DIA	1	
002	669-5497	HEX.HOLE BOLT 6X25S	2	
004	668-4741	STOP RING C-28, INNER	1	
005	668-4664	STOP RING C-12 OUTER	1	
006	669-5532	BALL BEARING #6001Z, 28MM/OD	1	
007	669-5530	BALL BEARING #6001, 28MM/OD	1	
009	668-8798	GEAR CASE	1	
011	669-5510	HEX HOLE BOLT 5X12	1	
012	669-4979	BOLT 6X8	1	
013	669-5530	BALL BEARING #6001, 28MM/OD	1	
015	668-8943	GEAR SHAFT L-M10X1.25	1	
016	669-6297	BALL BEARING #6202DD, 35MM/OD	1	
017	669-5296	STOP RING C-35, INNER	1	
018	668-9029	CUTTER HOLDER	1	
019	668-9051	CUTTER HOLDER CAP	1	
020	668-8993	PROTECTION COVER B	1	
021	669-5511	HEX HOLE BOLT 5X14	3	
022	668-9067	FIXING NUT L-M10X1	1	
026	669-5082	HEX HOLE SCREW 6X30	2	
028	669-0313	SAFETY GUARD BRACKET	1	
029	669-0265	SAFETY COVER	1	
030	669-0342	SAFETY COVER HOLDER	1	
031	669-0374	COVER GUARD	1	
032	669-3386	KNIFE	1	
034	668-4753	TAPPING SCREW 5X20	1	
035	668-8879	GEAR PINION SET, SPARE	1	
036	668-8915	GEAR CASE COVER	1	
037	669-5077	HEX HOLE BUTTON SCREW 6X10	1	

B34-11



CG47EJ(T) TOOL/OPTIONAL PARTS



REF. NUMBER	PARTS NUMBER	DESCRIPTION	QTY	SERIAL NUMBER
001	669-352	HEX. WRENCH 4	1	
003	669-342	SPANNER 8X10	1	
007	669-357	COMBI, BOX WRENCH 17X1	1	
010	669-350	CUTTING BLADE 3TX305XT	1	
030	668-476	SAFETY GLASSES	1	
035	669-201	CUTTER COVER	1	

B34-12

CG47EJ(T) LABELS



REF. NUMBER	PARTS NUMBER	DESCRIPTION	Q'TY	SERIAL NUMBER
001	669-414	NAMEPLATE CG47EJ(T)	1	
002	669-461	SYMBOL MARK CG47EJ(T)	1	
008	668-485	CAUTION MARK 9900RPM	1	