LIST NO. F861


ELECTRIC TOOL PARTS LIST


■ CORDLESS KIT Model KC 24DC

2001 · 8 · 30

(E1)







PARTS KC 24DC

NO.	CODE NO.	DESCRIPTION	NO. USED	REMARKS	
1		MODEL CR 24DV CORDLESS SABER SAW	1		
2		MODEL C 7D CORDLESS CIRCULAR SAW	1		
3		MODEL UC 24YFB CHARGER	1		
4	320-269	CASE (B)	1		