


B47

Tanaka


TBC-230SF

B47-01 TBC-230SF CYLINDER/PISTON/CRANK SHAFT




REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
001	157-01570-90	1	
002	018-00555-20	1	
006	001-07130-91	1	
007	994-61050-184	2	
009	017-0631A-20	1	
011	041-00601-21	1	
012	030-00070-90	1	
013	039-00601-20	2	
014	037-06500-20	1	
016	046-07130-80	1	
017	999-62081-225	1	
018	068-10100-20	1	
040	178-20546-20	1	
043	167-20546-80	1	
046	994-63040-154	2	
050	167-20546-91	1	
056	560-20517-20	1	
057	191-07025-90	1	

B47-02 TBC-230SF CRANK CASE




REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
019	330-00200-21	V	
019	330-00200-22	V	
019	330-00200-23	V	
019	330-00200-24	V	
031	072-07120-90	1	
032	999-66122-200	2	
033	999-61600-115	2	
034	090-06410-20	1	
036	994-61050-184	3	
051	155-20550-80	1	
052	992-01080-011	1	
054	991-01080-011	1	

B47-03 TBC-230SF ENGINE-1




REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
040	403-0631A-20	1	
041	404-0099F-90	1	
042	402-0602K-21	1	
047	994-64050-224	2	
055	994-14050-601	2	
056	992-01050-011	2	
059	223-07000-90	1	
060	680-00731-20	1	
061	675-04042-80	1	
062	591-07135-21	1	
063	595-01690-90	1	
064	659-00801-20	3	
065	455-07142-90	1	
067	994-63050-164	2	
068	994-63050-205	1	
073	626-32550-20	1	
078	700-03005-08	1	
079	534-32710-20	1	

B47-04 TBC-230SF ENGINE-2




REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
001	738-06541-22	1	
002	380-06410-20	1	
003	992-01040-061	1	
004	990-73045-124	1	
005	990-51050-503	2	
006	992-01050-061	2	
007	704-07001-90	1	
008	992-10040-062	1	
016	737-07000-20	1	
017	133-06540-20	1	
030	257-07124-20	1	
031	359-02103-20	2	
032	290-06410-80	2	
033	342-06410-20	1	
034	348-06540-20	2	
035	357-00601-20	2	
036	994-64050-184	2	
038	992-05080-030	2	
039	990-72045-204	1	
045	994-64050-304	1	
063	198-11600-80	1	
070	202-10200-20	1	
071	011-06410-20	1	

B47-05 TBC-230SF RECOIL STARTER




REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
000	762-07085-90	1	
001	785-07085-20	1	
002	772-07085-80	1	
003	783-07085-20	1	
004	780-07085-20	1	
006	778-07085-91	1	
008	774-07085-21	1	
009	182-07085-20	1	
010	990-72050-144	1	
015	806-07120-20	1	
016	990-73045-144	3	
017	994-64040-125	4	
020	798-07085-90	1	
021	991-91050-001	1	

B47-06 TBC-230SF AIR CLEANER




REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
000	410-07142-91	1	
001	452-00070-22	1	
002	421-00070-20	1	
003	380-0637C-20	1	
004	423-00070-81	1	
006	528-07143-20	1	
007	992-04080-031	1	
008	657-3252A-20	1	

B47-07 TBC-230SF CARBURETOR




REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
002	575-25153-80	1	
003	442-25151-80	1	
004	476-25151-20	1	
005	447-25108-20	1	
006	474-25241-80	1	
007	475-25153-20	1	
008	576-25100-20	1	
009	577-25100-20	1	
010	599-2000W-40	1	
011	550-25100-20	1	
012	489-25100-20	1	
013	539-25120-20	1	
014	488-25145-80	1	
015	548-25140-20	2	
020	548-25151-20	4	
201	578-25007-20	1	

B47-08 TBC-230SF FAN CASE




REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
001	289-07060-80	1	
005	599-07120-21	1	
006	990-51050-163	1	
008	994-61050-254	1	
011	112-07124-80	1	
015	360-00996-20	1	
026	992-01050-061	1	
027	324-37350-20	1	
028	361-00990-20	1	

B47-09 TBC-230SF OPERATION PIPE




REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
001	035-38466-80	1	
002	341-38466-80	1	
003	347-38360-90	3	
020	280-38466-90	1	
021	320-33318-20	1	
022	360-33315-20	1	
023	358-10112-20	1	
024	993-50010-002	1	
025	871-32600-20	1	
026	512-3338P-20	1	
027	990-21060-504	1	
028	990-53060-353	1	
029	992-10060-062	1	
030	992-00060-061	1	
031	991-42060-012	1	
032	994-61050-124	1	
033	341-38466-80	1	
034	347-38360-90	3	
035	036-38190-20	1	
036	347-38466-20	1	

B47-10 TBC-230SF THROTTLE LEVER





REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
004	991-01060-041	2	
005	500-37300-20	1	
006	520-37277-20	1	
008	994-23060-432	2	
016	334-38360-20	1	
017	335-38360-80	1	
018	337-38360-80	1	
019	994-16050-252	1	
025	870-38449-90	1	
050	746-3738F-90	1	
083	885-38449-80	1	
084	887-38449-80	1	
085	156-37821-80	1	
086	164-07014-50	1	
098	253-38400-20	1	
100	832-38400-20	1	
103	322-38400-20	1	
110	994-31050-203	2	
111	991-01050-043	2	
112	993-46040-202	4	
125	880-38400-20	1	

B47-11 TBC-230SF GEAR CASE/SAFETY GUARD



REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
001	300-38360-91	1	
002	994-61050-254	1	
004	993-51024-002	1	
005	993-50009-002	1	
006	999-61609-002	1	
009	300-38360-21	1	
011	994-16050-121	1	
012	316-38150-20	1	
013	999-61626-000	1	
015	304-38360-20	1	
016	999-61600-003	1	
017	993-51026-002	1	
018	310-38360-20	1	
019	311-38360-20	1	
020	308-38360-20	1	
022	313-38360-20	1	
026	994-81060-254	2	
028	442-38455-20	1	
029	441-37380-20	1	
030	445-37380-20	1	
031	447-37380-20	1	
032	797-37380-21	1	
034	994-14050-121	1	
035	301-38360-00	1	
036	991-01050-011	1	
037	444-37609-20	1	
045	303-38360-20	1	
046	994-16050-121	1	

B47-12 TBC-230SF TOOLS/OPTIONAL PARTS



REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
005	829-20000-80	1	
030	813-20000-20	1	