

B21


Tanaka

TBC-420PF / 430PF

Serial No.

B21-01


TBC-420PF / 430PF CYLINDER / PISTON / CRANK SHAFT



REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
005	255-04200-20	1	
006	157-11666-90	1	
008	018-00555-20	1	
011	001-04405-90	1	
012	994-61050-204	4	
014	017-04400-20	1	
015	041-04050-20	2	
016	030-04400-90	1	
017	037-01000-20	1	
018	039-05004-20	2	
021	046-04400-80	1	
022	999-62101-004	1	
031	068-02000-20	1	
043	167-20543-80	1	
044	560-20517-20	1	
045	178-20543-21	1	
046	167-20543-90	1	
050	191-04405-90	1	
056	990-11040-182	2	
057	992-10040-012	2	
058	992-00040-011	2	
059	182-0186A-20	2	
063	198-11600-80	1	

B21-02


TBC-420PF / 430PF CRANK CASE



REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
007	257-04400-20	1	
009	994-63050-204	1	
019	788-0162V-20	1	
020	993-55050-000	1	
023	991-11100-013	1	
024	790-0162V-20	1	
025	798-04220-90	1	
026	072-04400-90	1	
027	090-04400-20	1	
028	999-66152-500	2	
029	999-61620-200	2	
032	071-02007-20	V	
032	071-02007-21	V	
032	071-02007-22	V	
032	071-02007-23	V	
032	071-02007-24	V	
036	994-61050-304	4	
051	155-20538-80	1	
052	992-01100-001	1	
054	991-01100-011	1	
066	112-04300-20	1	
067	994-61050-204	4	
069	203-11660-20	1	

B21-03


TBC-420PF / 430PF ENGINE-1



REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
001	738-0440A-20	1	
003	994-61050-124	1	
004	994-61050-164	1	
005	990-53060-653	2	
006	992-01060-011	2	
007	704-04400-90	1	
008	992-01050-061	2	
010	721-04400-20	1	
011	994-34040-081	1	
013	732-04400-20	1	
014	737-04230-20	1	
016	133-04400-20	1	
023	994-63050-204	4	
024	203-0604A-20	1	
081	359-10112-20	2	
082	290-04200-81	2	
083	342-04200-20	1	
084	992-04100-030	2	
085	357-04201-20	2	

B21-04


TBC-420PF / 430PF ENGINE-2



REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
031	403-04300-20	1	
032	404-04300-90	1	
033	402-04300-20	1	
034	453-0637C-20	1	
035	470-0602N-20	1	
036	423-01380-82	1	
037	528-01380-21	1	
038	476-01700-20	1	
039	446-01380-20	1	
040	992-04080-031	1	
041	452-01380-91	1	
042	380-0637C-20	1	
043	990-11050-602	2	
044	992-10050-012	2	
045	455-04400-90	1	
049	990-11050-252	2	
050	992-10050-012	2	
051	992-00050-011	2	
063	223-01251-90	1	
064	680-00731-20	1	
065	675-01630-90	1	
066	591-04400-21	1	
068	659-04300-20	3	
070	595-00072-90	1	
072	561-00070-20	1	
073	646-3252L-90	1	
074	565-04400-20	1	
075	564-04400-90	1	
076	994-63050-204	3	
077	940-04300-20	1	
078	700-03005-08	1	
079	680-00206-20	1	
080	222-06300-20	1	
086	626-32550-20	1	

B21-05


TBC-420PF / 430PF RECOIL STARTER



REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
000	762-04220-90	1	
001	772-04220-80	1	
002	769-04220-20	1	
003	779-04220-20	1	
009	783-04220-20	1	
012	835-04220-20	1	
014	785-04220-20	1	
017	839-04220-20	1	

B21-06

TBC-420PF / 430PF CARBURETOR




REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
001	514-25100-20	2	
004	544-25164-20	1	
005	539-25120-20	1	
006	549-25165-20	1	
007	489-25100-20	1	
008	488-25183-80	1	
009	614-25137-20	1	
010	550-25100-20	1	
011	599-2001W-44	1	
012	613-25100-20	1	
013	577-25100-20	1	
014	576-25100-20	1	
017	578-25007-20	1	
018	575-25153-80	1	
019	475-25153-20	1	
020	474-25001-80	1	
021	476-25151-20	1	
022	548-25151-20	4	
024	431-0634C-20	1	
025	442-25151-80	1	
026	447-25108-20	1	

B21-07

TBC-420PF / 430PF CLUTCH CASE

TBC-420PF




REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
001	289-04300-80	1	
002	999-61620-202	2	
003	993-50015-002	1	
004	331-04300-20	1	
005	991-91050-001	1	
006	599-04300-20	1	
009	990-74045-164	1	
011	990-53060-203	4	
012	990-54050-253	1	
015	360-04300-20	1	
020	096-04300-20	1	

B21-08

TBC-420PF / 430PF CLUTCH CASE

TBC-430PF




REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
001	289-04205-80	1	
002	996-61620-202	2	
003	993-50015-002	1	
004	331-04405-20	1	
005	347-04201-20	1	
006	994-61050-164	4	
009	599-04201-80	1	
011	990-53060-203	4	
013	990-51050-103	1	
014	282-04201-20	1	
015	990-53060-453	1	
016	992-10060-062	1	
017	992-01060-061	1	
018	991-91060-061	1	

B21-09

TBC-420PF / 430PF OPERATION PIPE / HANDLE

TBC-420PF




REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
001	343-37850-20	1	
002	341-38100-80	1	
003	347-37850-90	5	
010	993-11052-012	1	
011	368-32350-20	1	
016	503-3738E-20	1	
017	994-23060-432	2	
018	500-3738E-20	1	
019	520-33398-20	1	
022	991-01060-041	2	
025	870-38103-90	1	
051	991-01050-041	1	
053	335-33682-20	1	
054	994-61050-164	1	
083	885-38103-80	1	
098	253-38400-20	1	
100	832-38400-20	1	
103	322-38400-20	1	
110	994-31050-203	2	
111	991-01050-043	2	
112	993-46040-202	4	
125	880-38400-20	1	

B21-10

TBC-420PF / 430PF OPERATION PIPE / HANDLE

TBC-430PF




REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
001	343-38101-20	1	
002	341-38101-80	1	
003	347-37100-90	5	
042	335-37121-20	1	
043	334-37121-20	2	
044	994-62050-304	2	
046	315-37304-20	1	
063	165-33130-20	1	
064	994-61050-224	4	
066	506-37130-20	1	
067	507-37130-20	1	
069	508-37130-20	1	
071	994-81060-214	2	
072	336-37540-20	1	
074	460-33111-20	1	
075	502-33674-21	1	
092	501-38102-20	1	
095	870-38401-90	1	
098	253-38400-20	1	
100	832-38400-20	1	
101	880-38401-20	1	
103	332-38400-20	1	
106	993-46040-202	2	
107	994-31050-303	1	
108	991-01050-043	1	
120	885-38401-80	1	

B21-11

TBC-420PF / 430PF GEAR CASE / GUARD

TBC-420PF




REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
001	300-38103-90	1	
002	994-61050-254	2	
004	993-51024-002	1	
005	993-50009-002	1	
006	999-61609-002	1	
007	999-61609-000	1	
009	300-37380-20	1	
011	990-51050-103	1	
012	994-23080-100	1	
013	999-61628-000	1	
015	304-37134-20	1	
016	999-61620-103	1	
017	993-51032-002	1	
018	310-37623-20	1	
019	311-37300-20	1	
021	308-33410-20	1	
022	312-33386-20	1	
023	324-37350-20	1	
025	067-37134-20	1	
026	994-81060-254	2	
028	442-33699-20	1	
029	441-38100-20	1	
030	445-37380-20	1	
031	447-38100-20	1	
032	797-37380-21	1	
034	994-14050-121	1	
035	301-37134-00	1	
036	991-01050-011	1	

B21-12

TBC-420PF / 430PF GEAR CASE / GUARD

TBC-430PF



REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
001	300-37100-93	1	
002	994-61050-254	2	
004	993-51028-002	1	
005	993-50012-002	1	
006	999-61600-102	1	
007	999-61600-100	1	
009	300-37100-22	1	
011	994-61050-124	1	
012	994-23080-100	1	
013	999-61600-000	1	
015	304-37100-21	1	
016	999-61620-303	1	
017	993-51040-002	1	
018	310-37100-21	1	
019	311-33386-20	1	
020	307-37100-81	1	
021	994-16050-162	3	
022	312-33386-20	1	
023	324-37110-20	2	
026	994-81060-254	2	
028	442-37121-20	1	
029	441-38102-20	1	
030	445-37380-20	1	
031	447-38100-20	1	
032	797-37380-21	1	
034	994-14050-121	1	
035	301-37100-00	1	
036	991-01050-011	1	
050	308-33410-20	1	