


B35

***Tanaka***

**TBC- 430PFLV**


***-Z249900***

# B35-01 TBC-430PFLV CYLINDER/PISTON/CRANK SHAFT




REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
005	255-04200-20	1	
006	157-11666-90	1	
008	018-00555-20	1	
011	001-04405-90	1	
012	994-61050-204	4	
014	017-04400-20	1	
015	041-04050-20	2	
016	030-04400-90	1	
017	037-01000-20	1	
018	039-05004-20	2	
021	046-04400-80	1	
022	999-62101-004	1	
031	068-02000-20	1	
043	167-20543-80	1	
044	560-20517-20	1	
045	178-20543-22	1	
046	167-20543-91	1	
050	191-04405-90	1	
056	994-16040-183	2	
059	182-0186A-20	2	
063	198-11600-80	1	

# B35-02 TBC-430PFLV CRANK CASE




REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
019	788-0162V-20	1	
020	993-55050-000	1	
023	991-11100-013	1	
024	790-0162V-20	1	
025	798-04220-90	1	
026	072-04400-91	1	
027	090-04400-20	1	
028	999-66152-564	2	
029	999-61620-200	2	
032	071-02007-20	V	
032	071-02007-21	V	
032	071-02007-22	V	
032	071-02007-23	V	
032	071-02007-24	V	
036	994-61050-304	4	
051	155-20538-80	1	
052	992-01100-011	1	
054	991-01100-011	1	

# B35-03 TBC-430PFLV ENGINE-1




REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
031	403-04300-20	1	
032	404-04300-90	1	
033	402-04300-20	1	
034	453-0637C-20	1	
035	470-01380-20	1	
036	423-01380-82	1	
037	528-01380-21	1	
038	476-01700-20	1	
039	446-01380-20	1	- Z249600
039	446-01380-21	2	Z249601 -
040	992-04080-031	1	
041	452-01380-91	1	
042	380-0637C-20	1	
043	990-11050-602	2	
044	992-10050-012	2	
045	455-04401-90	1	
046	786-00601-20	2	
049	994-16050-253	2	
062	649-01680-20	1	
063	223-01251-90	1	
064	680-00731-20	1	
065	675-01630-90	1	
066	591-04400-21	1	
068	659-04300-20	3	
070	595-00072-90	1	
072	561-00070-20	1	
073	646-3252L-90	1	
074	565-04400-21	1	
075	564-04400-91	1	
076	994-63050-204	2	
077	940-04300-20	1	
078	700-03005-08	1	
079	680-00206-20	1	
080	222-06300-20	1	
086	626-32550-20	1	
087	992-01050-061	1	
088	994-61050-304	1	

# B35-04 TBC-430PFLV ENGINE-2




REF. NUMBER	PARTS NUMBER	QTY	SERIAL NUMBER
001	738-0440A-21	1	
003	994-61050-124	1	
005	990-53060-653	2	
006	992-01060-011	2	
007	704-04400-90	1	
008	992-01050-061	1	
010	721-04400-20	1	
011	994-34040-081	1	
013	732-04400-20	1	
014	737-04230-20	1	
016	133-04400-20	1	
023	994-63050-204	2	
024	203-10000-20	1	
025	994-61050-254	2	
026	992-01050-061	2	
081	359-10112-20	2	
082	290-04200-81	2	
083	342-04200-20	1	
084	992-04100-030	2	
085	357-04201-20	2	

**B35-05 TBC-430PFLV RECOIL STARTER**




REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
000	762-04220-90	1	
001	772-04220-80	1	
002	769-04220-20	1	
003	779-04220-20	1	
009	783-04270-20	1	
012	835-04220-20	1	
014	785-04220-20	1	
017	839-04220-20	1	

# B35-06 TBC-430PFLV CARBURETOR



REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
001	514-25100-20	2	
004	544-25164-20	1	
005	539-25120-20	1	
006	549-25165-20	1	
007	489-25100-20	1	
008	488-25183-80	1	
009	614-25137-20	1	
010	550-25100-20	1	
011	599-2001W-44	1	
012	613-25100-20	1	
013	577-25100-20	1	
014	576-25100-20	1	
017	578-25007-20	1	
018	575-25153-80	1	
019	475-25153-20	1	
020	474-25001-80	1	
021	476-25151-20	1	
022	548-25151-20	4	
024	431-0634C-20	1	
025	442-25151-80	1	
026	447-25108-20	1	


# B35-07 TBC-430PFLV FAN CASE



REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
001	289-04308-80	1	
003	999-61620-201	1	
004	993-51035-002	1	
007	257-04400-20	1	
009	994-63050-204	1	
015	990-54060-253	1	
055	994-14050-101	1	
060	132-04400-20	1	
066	112-04308-22	1	
067	994-61050-204	4	
069	203-11660-20	1	




# B35-08 TBC-430PFLV OPERATION PIPE




REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
001	343-38101-20	1	
002	341-37860-80	1	
003	347-37100-90	5	
011	512-37861-80	1	
013	506-37861-20	1	
014	507-37861-20	1	
015	522-37861-20	1	
016	521-37861-80	1	
017	315-37861-20	1	
018	326-37180-21	4	
020	991-87060-001	1	
021	990-54060-303	1	
063	165-37861-20	1	
074	198-37861-21	3	
091,1	746-37455-91	1	- Y254260
091	746-37180-90	1	Y254261 -
092	501-37861-21	1	
093	198-3332A-20	1	

# B35-09 TBC-430PFLV THROTTLE LEVER




REF. NUMBER	PARTS NUMBER	QTY	SERIAL NUMBER
084	164-07093-00	1	
095	870-38110-90	1	
098	253-38400-20	1	
100	832-38400-20	1	
101	880-38401-20	1	
103	322-38400-20	1	
106	993-46040-202	2	
107	994-31050-303	1	
108	991-01050-043	1	
110	156-38110-80	1	
120	887-38110-80	1	
125	885-38110-80	1	

# B35-10 TBC-430PFLV GEAR CASE/GUARD



REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
001	300-37861-91	1	
002	994-61050-254	2	
004	993-51028-002	1	
005	993-50012-002	1	
006	999-61600-102	1	
007	999-61600-115	1	
009	300-33392-21	1	
011	994-61050-124	1	
012	994-23080-100	1	
013	999-61600-000	1	
015	304-37850-21	1	
016	999-61620-303	1	
017	993-51040-002	1	
018	310-37100-22	1	
019	311-37861-20	1	
020	307-37100-81	1	
021	994-16050-162	3	
022	313-38100-20	1	
023	324-37110-20	2	
026	994-81060-254	2	
028	442-37121-20	1	
029	441-37130-20	1	
030	445-37380-20	1	
031	447-37380-20	1	
032	797-37380-21	1	
034	994-14050-121	1	
035	301-37100-00	1	
036	991-01050-011	1	
045	327-37180-90	1	- W254355
050	308-37861-20	1	

# B35-11 TBC-430PFLV TOOLS



REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
004	814-20000-20	1	
030	813-20000-20	1	
031	826-20000-20	1	
035,1	615-37224-20	2	- Y254260
035	615-37181-20	1	Y254261 -