



K8016BLN

Pos. Nr.	Artikel Nr.	Beschreibung
101	T80BL-101	Deckel
102	T80BL-102	Dichtring
103	T80BL-103	Einsatz
104	T80BL-104	Zylinder
105	T80BL-105	O-Ring
106	T80BL-106	Manschette
107	T80BL-107	Kolbenring
108	T80BL-108	O-Ring
109	T80BL-109	Kolben kompl.
110	T80BL-110	Puffer
111	T80BL-111	Stösselführung
112	T80BL-112	Deckel
201	T80BL-201	O-Ring
202	T80BL-202	Ventilstange
203	T80BL-203	O-Ring
204	T80BL-204	Puffer
205	T80BL-205	O-Ring
206	T80BL-206	Ventilkopf
207	T80BL-207	O-Ring
208	T80BL-208	Ventil-Oberteil
209	T80BL-209	Feder
210	T80BL-210	O-Ring
211	T80BL-211	Stange
212	T80BL-212	Dichtring
213	T80BL-213	Ventildeckel
214	T80BL-214	Schraube
215	T80BL-215	Abzug
216	T80BL-216	Stift

Pos. Nr.	Artikel Nr.	Beschreibung
218	T80BL-218	Feder
219	T80BL-219	Auslösesicherung
220	T80BL-220	Drehfeder
221	T80BL-221	Stift
301	T80BL-301	Gehäuse
303	T80BL-303	Führungsring
304	T80BL-304	Deckel-Hinten
305	T80BL-305	Nippel
306	T80BL-306	Staubschutz
401	T80BL-401	Schraube
402	T80BL-402	Schraube
403	T80BL-403	Werkzeugplatte
404	T80BL-404	Distanzplatte
405	T80BL-405	Magazin Oberteil
406	T80BL-406	Sondermutter
407	T80BL-407	Winkel
408	T80BL-408	Schraube
409	T80BL-409	Unterlagscheibe
410	T80BL-410	Schraube
411	T80BL-411	Magazinschieber
412	T80BL-412	Magazin Unterteil
413	T80BL-413	Deckel
414	T80BL-414	Drehfeder
415	T80BL-415	Einrasthebel
416	T80BL-416	Stift
417	T80BL-417	Rastscheibe
418	T80BL-418	Zugfeder