



Repère	Code	Français	English	Deutsch
101	12B03157	Défecteur	Deflector	Deflektor
102	12B02697	Filtere	filter	Filter
103	12B02845	Vis C HC M4-20	Bolt w/flat washer	Schraube
104	12B02699	Entretoise	Collor	Zwischenteil
105	12B03158	Couvercle	Cap	Deckel
106	12B03159	Câble haute tension	High voltage cable set	Hochspannungkabel
107	12B02702	Bougie	Sparkler unit	Zündkerze
108	12B02546	Circlips	C-ring	C-Ring
109	12B02703	Vis	Screw	Schraube
110	12B02733	Silentbloc	Feed bumper	Puffer
111	12B02704	Plaque de centrage	Fan motor bracket	Positionierblatt
112	12B02705	Moteur	Motor unit	Motor
113	12B02594	Circlips	C-Ring	C-Ring
114	12B02550	Manchon moteur	Sleeve motor	Muffe
115	12B02551	Rondelle	Washer-motor shaft	Scheibe
116	12B02706	Injecteur	Fuel stem adapter	Gas adapter
117	12B02707	Culasse	End cap-combustion chamber	Zylinderkopf
118	12B02734	Vis C HC M4-6	Hex. Soc. Head bolt	Schraube
119	12B02708	Segment	Piston ring-cylinder	Kolbenring
120	12B02555	Rondelle	Seal	Scheibe
121	12B02556	Rondelle	Seal plate-motor	Scheibe
122	12B02557	Circlips	In-concentric ring	C-Ring
123	12B02558	Vis A HC M4-4	Hex. Soc. Head screw	Schraube
124	12B02710	Ventilateur	Cooling fan assy	Fan
125	12B02711	Joint	Spacer	Dichtung
126	12B00150	Vis C HC M4-14	Hex. Soc. Head bolt	Schraube
127	12B02712	Chambre de combustion sup.	Upper combustion chamber	Obere Brennkammer
128	12B02713	Joint	Packing	Dichtung
129	12B02714	chambre de combustion	Combustion chamber	Brennkammer
130	12B02715	Circlips	C-ring	C-Ring
131	12B02716	Segment	Piston ring	Kolbenring
132	12B03253	Piston	Driver unit	Kolben
133	12B02718	Amortisseur	Bumper	Puffer
134	12B02719	Cylindre	Cylinder	Zylinder
135	12B02720	Filtere	Exhaust mesh plate	Filter
136	12B02721	Joint	O-ring	O-Ring
137	12B02722	Support clapet	Exhaust baffle	Ventilplatte
138	12B02723	Clapet	Reed valve	Ventil
139	12B02724	Filtere	Cleaner B	Filter
140	12B02725	Défecteur	Deflector	Deflektor
141	12B01823	Vis C HC M4-10	Hex. Soc. Head bolt	Schraube

142	12B02726	Ressort	Safety spring	Feder
143	12B03254	Sécurité	Safety unit	Sicherung
144	12B02728	Vis C HC M4-8	Hex. Soc. Head bolt	Schraube
145	12B03255	Adaptateur	Link rod	Verbindungstange
146	12B03256	Sécurité A	Safety A	Sicherung A
147	12B03257	Goupille	Pin	Stift
148	12B02490	Ecrou nilstop M4	Lock nut	Mutter
149	12B02732	Levier	Motor fan switch lever	Schalthebel
201	12B02735	Ressort	Spring	Feder
202	12B02736	Gâchette	Trigger	Auslöser
203	12B02737	Goupille	Pin	Stift
204	12B02775	Ressort	Guide locating spring	Feder
205	12B02776	Arrêt	Stopper	Stopper
206	12B02777	Ressort	Spring	Feder
207	12B02778	Sécurité	Safety	Sicherung
208	12B02779	Goupille	Pin	Stift
209	12B02780	Block de liaison	Link-block	Kupplungsteil
210	12B02781	Ressort	Spring	Feder
301	12B03258	Corps	Gun body unit	Gehäuse
302	12B02783	Insert	Cap nut	Mutter
303	12B03161	Poignée A	Handle A unit	Griff A
304	12B02785	Ecrou nilstop M5	Lock nut	Mutter
305	12B00844	Vis	Tap bolt	Schraube
306	12B02786	Levier d'injection	Fuel actuator	Gas deckel
307	12B02614	Rouleau	Bush-fuel actuator	Zwischenteil
308	12B02612	Goupille	Pin-fuel actuator	Stift
309	12B02787	Vis	Tap bolt	Schraube
310	12B03163	Poignée B	Handle B unit	Griff B
311	12B02789	Vis C HC M5-25	Bolt w/flat washer	Schraube
312	12B03099	Connecteur batterie	Connecting unit	AKKU Stecker
313	12B03100	Couvercle LED	LED cover	LED Deckel
314	12B00046	Vis	Tap bolt	Schraube
315	12B02790	Couvercle	Wire harness plate	Platte
316	12B02791	Crochet	Spring retainer	Haken
317	12B02791	Rondelle	Flat washer	Scheibe
318	12B02793	Vis C HC M4-50	Hex.Soc. Head bolt	Schraube
319	12B03162	Module électronique	PCB assy	Elektronisches Modul
320	12B03259	Entretoise	Latch spring bushing	Zwischenteil
321	12B03260	Support	Bracket	Halterung
322	12B01298	Ressort	Stopper finger spring	Feder
323	12B00403	Ecrou	Bolt cap	Mutter
324	12B03264	Couvercle	Fixed support	Deckel
325	12B03265	Goupille	Spring pin	Stift
326	12B00470	Goupille	Spring pin	Stift
327	12B03266	Entretoise	Latch spring bushing	Zwischenteil
328	12B03267	Vis B HC M-	Half round head hex. Bolt	Schraube
401	12B03268	Nez	Driver guide	Nase
402	12B03269	Goupille	Pin	Stift
403	12B03270	Plaque avant	Driver guide cover	Vorderplatte
404	12B00933	Loquet	Lock handle unit	Verschlusshebel
405	12B01106	Goupille	Spiral pin	Stift
406	12B03271	Guide	Driver guide	Führung
407	12B03272	Vis B HC M-	Half round head hex. Bolt	Schraube
408	12B00934	Magasin A	Magazine A	Magazin A
409	12B00940	Vis	Special screw	Schraube
410	12B01020	Ressort	Spring	Feder
411	12B03273	Poussoir	Pusher	Kloben
412	12B00937	Ressort	Latch spring	Feder
413	12B00936	Loquet	Door latch	Verschlusshebel
414	12B00056	Circlips	E-ring	E-Ring
415	12B03274	Support	Bracket	Magazinträger
416	12B00947	Goupille	Hinge point	Stift
417	12B03166	Anneau de retenue	PU retainer	Sicherungsring
418	12B01736	Vis C HC M5-10	Hex. Soc. Head bolt	Schraube
419	12B03275	Couvercle	Mounting bracket	Deckel
420	12B00931	Ressort	Safety ring	Feder
421	12B02852	Goupille	Fixed pin	Stift
422	12B02853	Circlips	E-ring	E-Ring
423	12B00831	Molette de réglage	Adjust axie	Einstellrad
424	12B03276	Sécurité	Safety unit	Sicherung