
Model No. : EY45A5 Exploded View



Model No. : EY45A5 Parts List

Change	Safety	Ref. No.	Part No.	Part Name & Description	Q'ty	Remarks
		1	WEY45A5K3078	HOUSING AB ASSEMBLY	1	(FOR EUROPE/OCEANIA)
		2	WEY45A5K9127	TIGHT SCREW	14	(M4*16),(14PCS/PK)
		3	WEY45A5K6237	PAN HEAD SCREW	14	(M4*12),(14PCS/PK)
		4	WEY45A5K6087	PAN HEAD SCREW	1	(M5*12)
		5	WEY45A5H1567	LEVER	1	
		6	WEY45A5K6147	WAVE WASHER	1	
		7	WEY45A5K4727	COVER PLATE ASSEMBLY	1	
		8	WEY45A5K1377	SHAFT ASSEMBLY	1	
		9	WEY45A5S4347	SLIDE BLOCK ASSEMBLY	1	
		10	WEY45A5S0167	SPRING	1	
		11	WEY45A5S4998	MOUNTING BASE BLOCK	1	
		12	WEY45A5K0807	GUIDE A ASSEMBLY	1	
		13	WEY45A5K0817	GUIDE B ASSEMBLY	1	
	1	14	WEY45A5K6427	PAN HEAD SCREW	4	(M5*25),(4PCS/PK)
	1	15	WEY45A5K6447	SPRING WASHER	4	(4PCS/PK)
		16	WEY45A5K0887	FENCE	1	
		17	WEY45A5L2107	SWITCH AND MAIN MODULE	1	
		18	WEY45A5L6367	PAN HEAD SCREW	1	(M3*8), (5PCS/PK)
		19	WEY45A5L0187	SPRING PLATE	1	
		20	WEY45A5W0987	OFF LOCK RING	1	
		21	WEY45A5H3597	OFF LOCK LEVER	1	
		22	WEY45A5L0197	SPRING	1	
		23	WEY45A5K3958	CONTROL PANEL ASSEMBLY	1	
		24	WEY45A5X3097	LED COVER	1	
		25	WEY45A5K3747	MOTOR HOUSING	1	
		26	WEY45A5L1008	MOTOR AND GEAR CASE ASSY	1	
		27	WEY45A5L1417	TRANSMITTING GEAR	1	
		28	WEY45A5L6777	STOP RING	1	
		29	WEY45A5K3107	UPPER GUARD ASSEMBLY	1	
		30	WEY45A5K3117	LOWER GUARD ASSEMBLY	1	
		31	WEY45A5K6577	HEXAGON SOCKET SCREW	2	(M8*14), (2PCS/PK)
	1	32	WEY45A5L6667	PLAIN WASHER	2	(2PCS/PK)
	1	33	WEY45A5L6707	WASHER	3	(3PCS/PK)
		34	WEY45A5K1307	IDLER PULLEY	1	
		35	WEY45A5K1317	DRIVING PULLEY	1	
		36	WEY45A5K1097	RUBBER BELT	2	(2PCS/PK)
		37	WEY45A5K1897	GUIDE C ASSEMBLY	1	
		38	WEY45A5K6127	PAN HEAD SCREW	2	(M3*6), (2PCS/PK)
		39	WEY45A5L6047	PAN HEAD SCREW	4	(M4*8), (4PCS/PK)
		40	WEY45A5K9077	TIGHT SCREW	1	(M4*25), (5PCS/PK)
		41	WEY45A5L6307	BIND SCREW	2	(M5*16), (2PCS/PK)
		42	WEY45A5K3767	HOOK	1	
		43	WEY9L40R2788	BATTERY PACK COVER	1	
		-	WEY9664K7018	TOOL CASE	1	
		-	WEY45A5K8108	OPERATING INSTRUCTIONS	1	
		-	WEY6705X5527	SUNLIGHT GREASE	1	