


AIR20/240



AIR20/240 PARTS LIST

Pos. No	Article No	Description	QTY per unit
1	203010.032	Screw	12
2	205020.011	Cushion	12
3	311111.018	Cylinder Head	2
4	210003.004	Seal	2
5	203014.003	Screw	2
6	315111.002	Limit Range Implement	2
7	315211.005	Valve Block	4
8	315311.007	Valve Board	2
9	210002.007	O-Ring	2
10	315511.003	Valve Block clamp	2
11	203014.003	Screw	2
12	311311.009	Cylinder	2
13	203012.006	Screw	2
14	312111.004	Piston Cup Clamp	2
15	312711.006	Piston Cup	2
16	313112.008	Connecting Rod	2
17	311411.004	Heightening the lining	2
18	323211.003	Wind Scooper	2
19	203016.003	Screw	4
20	323112.007	A Fan	1
21	313411.010	Crank	2
22	208001.042	Bearing	2
23	203017.004	Screw	8
24	207002.004	circlip for shaft	2
25	203013.012	Screw	1
26	205022.001	Serrated Lock Washers Internal Teeth	1
27	326211.002	Power Cord Buckle	1
28	314111.007	Right Crankcase	1
29	205020.003	Cushion	4
30	201011.010	Bolt	4
31	321111.033	Motor Staotr	1
32	321311.009	Motor Rator	1
33	208001.034	Bearing	2
34	314111.008	Left Crankcase	1
35	204011.001	Nut	4
36	352212.005	Shock Pad	4
37	204011.003	Nut	4
38	323112.008	B Fan	1

AIR20/240 PARTS LIST

Pos. No	Article No	Description	QTY per unit
39	210002.003	O-Ring	4
40	311511.003	Gas-guide Tube	2
41	341111.002	Hush Pipe	2
42	353112.002	Air Filter	2
43	334111.014	Power Cord	1
44	352113.005	Handle Sleeve	3
45	401411.002	Handle	1
46	204011.003	Nut	2
47	205010.007	Flat washer	2
48	201010.018	Bolt	2
49	211002.001	Extension Spring	2
50	355311.001	Hand Rod	1
51	205010.003	Flat washer	2
52	203014.005	Screw	2
53	401811.002	Tool Plate	1
54	203012.004	Screw	4
55	201012.011	Bolt	4
56	352211.001	Foot Pad	2
57	351111.040	Tank	1
58	352313.001	Foot Wheel	2
59	352411.003	Foot shaft	2
60	352213.001	Foot Pad	2
61	205010.009	Flat washer	2
62	201012.013	Bolt	2
63	333611.001	Ball Valve	1
64	203018.001	Screw	8
65	343511.004	Elbow	2
66	344311.002	Nut	2
67	333311.020	Regulator Valve	1
68	203017.007	Screw	4
69	342111.007	Coupling	2
70	332211.018	Pressure Gauge	2
71	341111.004	Nylon Pipe	1
72	401611.007	Instrument Panel	1
73	333211.002	Soft Starter	1
74	343311.001	Three-way	1
75	316611.003	Seal cushion	4
76	341211.007	Exhaust Pipe	1

AIR20/240 PARTS LIST

Pos. No	Article No	Description	QTY per unit
77	333511.008	Check Valve	1
78	344211.001	Lining	2
79	341111.001	Nylon Pipe	1
80	344111.001	Ferrel	1
81	344311.001	Nut	1
82	343511.008	Elbow	1
83	341211.009	Exhaust Pipe	1
84	343511.009	Elbow	1
85	324111.006	Capacity	1
86	203014.002	Screw	2
87	324311.002	Capacity Cover	1
88	326211.003	Power Cord Buckle	2
89	324212.008	Thermal Protector	1
90	333111.003	CE safety valve	1
91	331112.050	Pressure Switch	1
92	342311.001	Flexible Joint	1
93	342312.001	Nut	1
94	316611.002	Gasket	2