



# HIKOKI

## CORDLESS JIG SAW CJ18DB

Item No.	Code No.	Description	No. Used	Remarks
1	379152	MICRO SWITCH (B) SET	1	
2	379150	HOLDER PLATE	1	
3	372288	TAPPING SCREW (W/FLANGE) D3X12	3	
4	379490	SPRING	1	
5	375867	SLIDE KNOB (A)	1	
6	379143	SWITCH COVER	1	
7	333916	WASHER	1	
8	696352	TAPPING SCREW D3X6	1	
9	379153	SWITCH COVER ASS'Y	1	INCLUD. 4-8
10	379142	HOUSING ASS'Y	1	INCLUD. 11
11	379492	SUPPORT (B)	1	
12	379145	MOTOR	1	
13	930196	SUPPORT (B)	3	
14	379146	GUARD BAR (A)	1	
15	379144	SWITCH CONTROLLER ASS'Y	1	INCLUD. 1
16	379151	DIAL	1	
17	379491	O-RING	1	
18	378683	BATTERY BSL 1850MA (EUROPE,AUS,NZL)	2	INCLUD. 502
19	301653	TAPPING SCREW (W/FLANGE) D4X20 (BLACK)	8	
20		NAME PLATE	1	
21	376481	LEVER SPRING	1	
22	375856	LEVER	1	
23	333916	WASHER	1	
24	332929	TAPPING SCREW (W/FLANGE) D3X20	1	
25	376473	PLUNGER COVER	1	
26	325077	SEAL LOCK HEX. SOCKET HD. BOLT M3X6	2	
27	376476	SPRING (C)	1	
28	376475	SPRING PLATE	1	
29	376487	PLUNGER HOLDER (B)	1	
30	376474	PACKING	1	
31	376467	WASHER (A)	2	
32	376480	RETAINING RING D15	1	
33	376472	PLUNGER (B)	1	
34	376604	NEEDLE ROLLER (C)	1	
35	982454	SPRING (C)	2	
36	376479	PLUNGER PIECE	1	
37	376478	HOLDER SPRING	1	
38	376477	HOLDER COVER	1	
39	376470	PLUNGER HOLDER (A)	1	
40	376471	PLUNGER (A)	1	
41	332829	CONNECTING PIECE (A)	1	
42	325242	NEEDLE BEARING	1	
43	376466	GEAR	1	
44	376469	BALANCE WEIGHT	1	
45	376468	ORBITAL CAM	1	
46	376460	PIN D6	1	
47	377886	RETAINING RING D7	1	
48	377887	WASHER (A)	1	
49	377885	GEAR HOLDER ASS'Y	1	INCLUD. 35, 47, 48, 50-55
50	673489	RETAINING RING (E-TYPE) FOR D5 SHAFT	1	
51	376683	NEEDLE ROLLER D4X24	1	
52	335297	STEEL BALL 5/32 (10 PCS.)	1	
53	338992	CHANGE KNOB	1	

\* ALTERNATIVE PARTS

# HIKOKI

## CORDLESS JIG SAW CJ18DB

Item No.	Code No.	Description	No. Used	Remarks
54	983545	NEEDLE ROLLER	1	
55	376465	ROLLER HOLDER	1	
56	375854	BASE	1	
57	375855	BASE PLATE	1	
58	321996	SPECIAL BOLT	4	
59	375857	MACHINE SCREW (W/WASHER) M4X5	1	
60	321576	RUBBER BUSHING	1	
61	339663	BASE LOCKER	1	
62	372724	HEX. SOCKET HD. BOLT M5X18	1	
		STANDARD ACCESSORIES		
501		CHARGER (MODEL UC 18YFSL)	1	
502	329897	BATTERY COVER	1	
503	944458	HEX. BAR WRENCH 4MM	1	
504	338997	SPLINTER GUARD	1	
505	879357	JIG SAW BLADES NO.41 (5 PCS.)	1	
506	379148	DUST COLLECTOR SET	1	
507	379147	CHIP COVER	1	
508	379149	INNER TRAY	1	
509	336471	CASE ASS'Y (STACKABLE 2)	1	INCLUD.510-512
510	336472	LATCH	4	
511	336473	HANDLE	1	
512	336474	HINGE	2	
		OPTIONAL ACCESSORIES		
601	321593	GUIDE	1	
602	339018	SUB BASE	1	
603	930035	GREASE (SEP-3A) (100G)	1	
604	372814	GREASE (NIPPECO BC-4) 75G	1	
605	325149	GREASE (MOLUB-ALLOY NO.777-1) 75G	1	
606	879336	JIG SAW BLADES NO.11 (5 PCS.)	1	
607	879337	JIG SAW BLADES NO.12 (5 PCS.)	1	
608	879338	JIG SAW BLADES NO.15 (5 PCS.)	1	
609	879339	JIG SAW BLADES NO.16 (5 PCS.)	1	
610	879340	JIG SAW BLADES NO.21 (5 PCS.)	1	
611	879341	JIG SAW BLADES NO.22 (5 PCS.)	1	
612	963400	JIG SAW BLADES NO.97 FOR STAINLESS(5PCS)	1	

\* ALTERNATIVE PARTS