


B44

CG47EJ(L)


Serial No.

B44-01 CG47EJ(L) CYLINDER/PISTON/CRANK SHAFT




REF. NUMBER	PARTS NUMBER	DESCRIPTION	Q'TY	SERIAL NUMBER
006	668-7473	SPARK PLUG CAP ASSY	1	
007	668-8336	SPARK PLUG RUBBER COVER	1	
008	668-5086	SPARK PLUG BPMR6A	1	
011	668-5471	CYLINDER SET	1	
012	668-4586	HEX.HOLE BOLT M5X18/S	4	
014	668-5733	CYLINDER GASKET	1	
015	668-6126	PISTON RING	2	
016	668-5887	PISTON SET	1	
017	668-6015	PISTON PIN 10X35	1	
018	668-6024	PISTON PIN CIRCLIP	2	
020	668-5994	PISTON PIN COLLAR	2	
021	668-6194	CRANK SHAFT COMP.	1	
022	669-5601	NEEDLE BEARING, 2X8.8	1	
031	668-6451	WOOD-RUFF KEY 3X13X5	1	

B44-02 CG47EJ(L) CRANK CASE




REF. NUMBER	PARTS NUMBER	DESCRIPTION	QTY	SERIAL NUMBER
023	669-513	SMALL NUT 10	1	
026	668-655	CRANK CASE ASSY	1	
027	668-671	CRANK CASE GASKET	1	
028	669-563	OIL SEAL UD15257	2	
029	669-555	BALL BEARING #6202, 35MM/OD	2	
030	668-646	CRANK SHAFT WASHER 15.2X22	2	
032	668-647	CRANK SHAFT SHIM 0.20	V	
032	668-647	CRANK SHAFT SHIM 0.30	V	
036	669-508	HEX HOLE BUTTON SCREW 6X45	2	
038	668-482	HEX SOCKET HD. BOLT (W/BUTTON) M6	2	
040	668-796	LEAD WIRE ASS'Y	1	
045	668-482	S. WASHER 6	4	
051	668-737	MAGNET ROTOR COMP.	1	
052	669-518	SMALL WASHER 10	1	
054	669-513	NUT 10	1	
055	668-764	IGNITION COIL COMP.	1	
056	669-533	SCREW 5X18/S	2	
058	668-486	SMALL WASHER 5	2	
063	668-800	CORD CLAMP COMP.	1	
066	668-697	FAN CASE, VERMILION	1	
067	669-536	SCREW 6X20/S	4	
068	668-805	PRIMARY CORD GROMMET	1	
069	668-804	PRIMARY CORD GROMMET	1	

B44-03 CG47EJ(L) ENGINE-1




REF. NUMBER	PARTS NUMBER	DESCRIPTION	Q'TY	SERIAL NUMBER
027	669-222	FUEL TANK CUSHION RUBBER	2	
031	668-988	INLET MANUFOLD GASKET	1	
032	668-995	CARB. INSULATOR SET	1	
033	668-982	CARBURETOR GASKET	1	
045	669-046	CARBURETOR ASSY	1	
049	669-542	SCREW 5X24WS	2	
051	669-100	CHOKE LEVER	1	
052	668-526	FUEL PIPE 2.5X4X90	2	
053	669-513	SMALL NUT 10	1	
054	669-523	INNER TOOTHED WASHER 10	1	
055	669-008	PRIMING PUMP COMP.	1	
063	668-816	FUEL PIPE ASSY 3X5X180	1	
064	668-461	CLIP, 6.3 DIA.	1	
065	669-227	PUMP FILTER BODY ASSY	1	
066	669-152	FUEL TANK, VERMILION	1	
068	668-462	RETURN GROMMET	1	
070	669-171	TANK CAP D ASSY, ORANGE	1	
076	669-192	TANK HOLDING BAND	1	
077	669-219	CUSHION RUBBER	1	
078	669-538	SCREW 5X16/PS	2	
096	668-462	TANK CAP CHAIN	1	

B44-04 CG47EJ(L) ENGINE-2




REF. NUMBER	PARTS NUMBER	DESCRIPTION	Q'TY	SERIAL NUMBER
001	669-277	MUFFLER PROTECTOR	1	
002	669-538	SCREW 5X12/PS	1	
003	668-466	HEX.HOLE BOLT M5X12/S	1	
004	668-491	WASHER M5	1	
005	669-508	HEX. HOLE BUTTON SCREW 6X65	2	
006	668-463	WASHER 6	2	
007	669-246	MUFFLER SET	1	
014	669-274	MUFFLER GASKET	1	
016	668-724	HEAT SHIELD	1	
023	669-538	SCREW 5X18/PS	2	
025	669-220	TANK BRACKET	1	
026	669-222	FUEL TANK CUSHION RUBBER	2	
081	668-964	CLUTCH WASHER B	2	
082	668-861	CLUTCH ARM	2	
083	668-942	CLUTCH SPRING	1	
084	669-520	WAVE WASHER 10	2	
085	668-962	CLUTCH STEP BOLT	2	

B44-05 CG47EJ(L) RECOIL STARTER




REF. NUMBER	PARTS NUMBER	DESCRIPTION	Q'TY	SERIAL NUMBER
000	669-297	RECOIL STARTER BODY ASS'Y	1	
001	669-302	RECOIL STARTER BODY COMP	1	
002	669-300	STARTER ROPE REEL	1	
003	669-311	RECOIL SPRING	1	
009	669-316	STARTER ROPE	1	
012	669-360	STARTER HANDLE CAP	1	
014	669-323	STARTER HANDLE	1	
017	669-363	SET SCREW	1	
019	669-330	STARTER PAWL	1	
020	668-468	STOP RING E-5	1	
023	669-539	SCREW 5X25PS	2	
024	669-334	STARTER PAWL SPRING	1	
025	669-339	STARTER PULLEY	1	

B44-06 CG47EJ(L) AIR CLEANER




REF. NUMBER	PARTS NUMBER	DESCRIPTION	Q'TY	SERIAL NUMBER
036	669-0104	CLEANER BODY	1	
037	669-224	COLLAR 5.8	2	
038	669-084	BLOW OVER CHECK BOARD	1	
039	669-035	CLEANER ELEMENT	1	
041	669-014	CLEANER COVER ASS'Y	1	
042	669-038	COVER FIXING BOLT	1	
043	669-491	SCREW 5X60	2	
044	668-466	S.WASHER 5	2	

B44-07 CG47EJ(L) CARBURETOR




REF. NUMBER	PARTS NUMBER	DESCRIPTION	Q'TY	SERIAL NUMBER
001	668-521	SCREW	1	
002	669-142	PUMP BODY	1	
003	669-145	PUMP GASKET	1	
004	669-144	PUMP DIAPHRAGM	1	
005	668-470	INLET SCREEN	1	
017	669-076	IDLE ADJUST SPRING	1	
018	669-073	IDLE ADJUST SCREW	1	
022	668-521	NEEDLE VALVE	1	
023	669-087	VALVE SPRING	1	
024	669-081	CONTROL LEVER	1	
025	668-521	HINGE PIN	1	
026	668-521	HINGE PIN SET SCREW	1	
027	669-084	DIAPHRAGM GASKET	1	
028	669-082	METERING DIAPHRAGM COMP.	1	
029	669-043	AIR PURGE COMP.	1	
030	669-086	DIAPHRAGM COVER	1	
031	669-131	SET SCREW	4	

B44-08 CG47EJ(L) CLUTCH CASE




REF. NUMBER	PARTS NUMBER	DESCRIPTION	QTY	SERIAL NUMBER
001	668-8586	CLUTCH SHAFT COMP.	1	
002	669-5553	BALL BEARING #6202Z, 35M	2	
003	669-5283	STOP RING C-15, OUTER	1	
004	668-9194	CLUTCH CASE	1	
006	669-1823	CUSHION RUBBER	1	
009	669-5046	HEX. HOLE BOLT 5X16	1	
011	668-5064	HEX. SOCKET HD. BOLT (W)	4	
012	669-5093	HEX HOLE BOLT 5 X 25	1	
015	668-9653	PIPE HOLDER	1	
026	668-4914	WASHER M5	1	
028	668-9664	METAL FITTING	1	

B44-09 CG47EJ(L) OPERATION PIPE





REF. NUMBER	PARTS NUMBER	DESCRIPTION	Q'TY	SERIAL NUMBER
001	668-9475	DRIVE SHAFT	1	
002	668-9400	DRIVE SHAFT COMP.	1	
003	668-9522	BUSH ASS'Y, 8 DIA.	5	
010	669-5255	TAPPING SCREW 5X20	1	
011	668-9681	BRAKE SHAFT WASHER	1	
016	669-1098	HANDLE GRIP	1	
017	668-4838	BOLT 6X43/P (BLACK)	2	
018	669-1049	LOOP HANDLE, 26DIA., BLA	1	
019	669-1231	BARRIER, 26 DIA, BLACK	1	
022	668-4835	HEX.NUT 6	2	
025	669-3731	THROTTLE LEVER ASS'Y	1	
038	669-4029	CONNECTOR CASE	1	
039	669-3886	THROTTLE WIRE 155+57.5	1	
040	668-7520	SPLIT PROTECTION TUBE,	1	
051	668-5058	NUT 5	1	
053	668-9264	LIFTING METAL	1	
054	668-4903	HEX.HOLE BOLT M5X16/S	1	
056	669-2874	SHOULDER BELT ASS'Y	1	
083	669-3957	THROTTLE WIRE COMP.	1	
084	669-4010	THROTTLE WIRE	1	
085	668-7442	STOP SWITCH COMP.	1	
086	668-7519	SPLIT PROTECTION TUBE,	1	
098	668-4721	SAFETY LEVER	1	
100	668-4722	RETURN SPRING	1	
110	668-4803	SCREW M5X20	2	
111	668-4727	CONTAL NUT 5	2	
112	668-4725	SCREW M4X20 (BLACK)	4	
125	668-4804	THROTTLE LEVER	1	

B44-10 CG47EJ(L) GEAR CASE/GUARD




REF. NUMBER	PARTS NUMBER	DESCRIPTION	QTY	SERIAL NUMBER
001	668-8696	GEAR CASE ASSY, 26 DIA.	1	
002	668-4709	HEX.HOLE BOLT M5X25/S	2	
004	669-5294	STOP RING C-26, INNER	1	
005	669-5319	STOP RING OUTER 10	1	
006	669-5526	BALL BEARING #6000Z, 26MM/OD	1	
007	669-5524	BALL BEARING #6000, 26MM/OD	1	
009	668-8770	GEAR CASE 26 DIA	1	
011	668-4667	HEX.HOLE BOLT M5X12/S	1	
012	668-9109	OILING BOLT	1	
013	668-4734	BALL BEARING 609	1	
015	668-8924	GEAR SHAFT	1	
016	669-5554	BALL BEARING 6201D, 32MM/OD	1	
017	669-5294	STOP RING C-32, INNER	1	
018	668-9032	CUTTER HOLDER	1	
019	668-9054	CUTTER HOLDER CAP	1	
022	668-9073	FIXING NUT M10X1.25	1	
023	668-9160	GEAR CASE WASHER	1	
026	668-4714	HEX.HOLE BUTTON SCREW 6X25S	2	
028	669-0314	COVER BRACKET 26	1	
029	669-0276	BLADE GUARD 26CE	1	
030	668-4748	SAFETY COVER HOLDER	1	
031	669-0376	BLADE GUARD	1	
032	668-4750	KNIFE	1	
034	668-4751	TAPPING SCREW 4X14	1	
035	668-8874	GEAR/PINION SET, SPARE	1	
038	668-4752	TAPPING SCREW 5X20	1	
039	668-4754	KNIFE	1	
040	668-8986	WINDING PROTECTOR COVER	1	

B44-11 CG47EJ(L) TOOLS/OPTIONAL PARTS



REF. NUMBER	PARTS NUMBER	DESCRIPTION	Q'TY	SERIAL NUMBER
000	669-321	NYLON HEAD TH97LM	1	
001	669-327	CUTTING BODY ASS'Y	1	
002	669-332	EYELET	2	
004	669-324	ADJUSTMENT BASE	1	
005	669-337	SPRING (SILVER)	1	
006	669-336	ADJUSTMENT WASHER	1	
007	669-329	CORD REEL BK	1	
008	669-227	STEEL BALL	3	
009	669-335	REEL SLIDER	1	
010	669-333	CUTTING BODY CAP	1	
012	668-909	MOUNTING NUT, L-M10X1.2	1	
030	668-481	HEX. BAR WRENCH 4MM	1	
031	668-476	BOX WRENCH (HEX. SOCK	1	
032	668-476	SAFETY GLASSES	1	

B44-12 CG47EJ(L) LABELS



REF. NUMBER	PARTS NUMBER	DESCRIPTION	Q'TY	SERIAL NUMBER
001	669-414	NAME PLATE(CG47EJ(L))	1	
002	669-461	SYMBOL MARK(CG47EJ(L))	1	
008	668-485	CAUTION MARK 9900RPM	1	