

ELECTRIC TOOL PARTS LIST


■ CORDLESS KIT
Model KC 18DB

2001·7·30


(E1)




①




②



③



④



⑤

