



H02


Tanaka

THT-210

Serial No. - R078200




REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
001	157-06500-91	1	
002	018-06540-21	1	
003	002-06500-20	1	
004	990-11050-201	2	
005	992-10050-012	2	
006	992-00050-011	2	
007	017-06500-20	1	
008	041-00601-21	1	
009	031-06500-20	1	
010	037-06500-20	1	
011	039-01620-20	2	
012	046-06500-80	1	
013	999-62081-225	1	
027	153-21532-90	1	
028	994-16040-226	2	
036	250-06500-20	1	
037	178-06500-80	1	R078201-
038	167-21532-80	1	R078201-

H02-02**THT-210 CRANK CASE**


REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
021	072-06500-90	1	
022	090-06500-20	1	
023	999-66122-269	2	
024	999-61600-100	2	
025	330-00200-21	V	
025	330-00200-22	V	
025	330-00200-23	V	
025	330-00200-24	V	
026	599-00601-20	1	
029	992-10050-012	3	
030	990-11050-301	3	
031	155-21523-80	1	
032	992-01080-011	1	
033	992-10080-012	1	
034	991-01080-011	1	
035	100-02100-20	2	

H02-03


THT-210 ENGINE-1



REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
025	403-06500-20	1	
026	404-06500-80	1	
027	994-16050-252	2	
030	402-06500-20	1	
033	999-67015-000	1	
035	423-06500-80	1	
036	470-06500-20	2	
037	528-0650T-20	1	
038	992-04080-031	1	
039	476-01700-20	1	
040	992-10050-012	2	
041	990-11050-602	2	
043	446-06500-20	1	
044	452-06500-20	1	
045	380-0637C-20	1	
050-1	700-13005-11	1	-P003885
050-1	700-53005-13	1	P003886-
050-1	700-53005-13	1	-R078200
050	223-06500-90	1	R078201-
051	680-00731-20	1	
052-1	675-0641E-90	1	-P003885
052	675-04042-80	1	P003886-
053-1	591-06500-20	1	-R078200
053	591-06500-21	1	R078201-
055	659-00801-20	2	
056	992-01050-011	2	-L265300
057	992-10050-012	2	-L265300
058-1	990-11050-181	2	-L265300
058	994-63050-185	2	L265301-
063	595-0650R-90	1	
086	626-32810-20	1	



REF.No.	PARTS No.	Q'ty	SERIAL No.
25	403-06500-20	1	
26	404-06500-90	1	
27	994-16050-252	2	
30	402-06500-20	1	
33	999-67015-000	1	
35	423-06500-81	1	
36	470-06500-20	2	
37	528-0650T-20	1	-U091000
37	528-06500-20	1	U091001-
38	992-04080-031	1	
39	476-01700-20	1	
40	992-10050-012	2	
41	990-11050-602	2	
43	446-06500-20	1	
44	452-06500-91	1	
45	380-0637C-20	1	
46	455-0651 E-90	1	-U091000
46	455-06504-90	1	U091001-
050-1	700-13005-11	1	-P003885
050-1	700-53005-13	1	-R078200
50	223-06500-90	1	R078201-
51	680-00731-20	1	
052-1	675-0641 E-90	1	-P003885
52	675-04042-80	1	P003886-
053-1	591-06500-20	1	-R078201
53	591-06500-21	1	-U091000
53	591-06504-21	1	U091001-
55	659-00801-20	2	
56	992-01050-011	2	-L265300
57	992-10050-012	2	-L265300
058-1	990-11050-181	2	-L265300
58	994-63050-185	2	L265301-
63	595-00093-90	1	
70	442-25143-80	1	U091001-
77	700-02504-08	1	U091001-
78	700-02504-06	1	U091001-
79	534-32710-20	1	U091001-




REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
003	738-06500-20	1	
004	737-06500-20	1	
005	133-06500-20	1	
006	706-06500-80	1	
007	992-01050-011	2	
008	990-51050-503	2	
011	112-06500-80	1	
012	780-06097-20	1	
013	774-06097-20	1	
014	801-06091-20	1	
015	839-00025-20	1	
016	798-06500-90	1	
017	203-0604A-20	1	
018	783-06097-20	1	
019	785-06410-20	1	
020	994-15040-162	3	
021	751-06500-20	1	
022	721-06504-80	1	
023	992-10040-012	2	
024	990-11040-081	2	
047	277-0634F-90	1	
061	990-72045-164	1	
062	994-25040-128	2	
065	790-06097-20	1	
066	788-06500-20	1	


H02-05 THT-210 CARBURETOR

Primer-Vergaser ab Ser. U050318 □

455-06504-90



REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
000	455-25145-90	1	
001	548-25140-20	2	
005	539-25120-20	1	
007	489-25100-20	1	
008	488-25145-80	1	
010	550-25100-20	1	
011	599-2000W-41	1	
013	577-25100-20	1	
014	576-25100-20	1	
015	523-25100-20	1	
016	522-25100-20	1	
017	578-25007-20	1	
018	575-25140-80	1	
019	475-25001-20	1	
020	474-25001-80	1	
021	476-25004-20	1	
022	548-25101-20	4	




REF.No.	PARTS No.	Q'ty	SERIAL No.:
0	455-25145-90	1	-S238370
1	548-25140-20	2	
5	539-25120-20	1	
7	489-25100-20	1	
8	488-25145-80	1	
10	550-25100-20	1	
11	599-200AW-41	1	-U091000
11	599-2000W-40	1	U091001-
13	577-25100-20	1	
14	576-25100-20	1	
15	523-25100-20	1	-S238370
16	522-25100-20	1	-S238370
17	578-25007-20	1	
18	575-25140-80	1	-S238370
18	575-25152-80	1	-T023959
18	575-25147-80	1	U091001-
19	475-25001-20	1	-U091000
19	475-25038-20	1	U091001-
20	474-25001-80	1	
21	476-25004-20	1	
22	548-25101-20	4	


Primer-Vergaser ab Ser. U050318 □
455-06504-90

H02-06

THT-210 FRONT HANDLE




REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
037	058-33160-20	1	
038	992-00060-011	2	
039-1	991-61060-011	1	-P223130
039	991-01060-011	1	P223131-
040	990-21060-551	1	-P223130
040	990-21060-501	1	P223131-
041	266-32750-20	2	
042	276-32710-20	2	
043	368-32057-20	2	
044	992-10050-012	2	
045	990-11050-301	2	
046	294-33160-20	1	-P223130
046	294-33160-21	1	P223131-
047	885-06500-80	1	
050	249-33160-20	1	
051	276-32710-20	2	
052	266-32750-20	2	
053	368-32057-20	2	
054	992-10050-012	2	
055	990-11050-301	2	
056	990-73045-124	4	
057	250-33160-20	1	
058	990-73045-124	1	
061	210-33160-20	1	
062	040-33160-80	1	
063	992-01050-011	2	
064	992-10050-012	2	
065	990-11050-401	2	
073	164-07007-00	1	

H02-07**THT-210 REAR HANDLE**

REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
025	050-33160-20	1	
026	170-33160-80	1	
027	258-11600-20	1	-P103240
027	258-11650-20	1	P103241-
028	994-31030-101	1	
029	230-33160-20	1	
030	231-33160-20	1	
031	232-33160-20	1	
032	064-32530-20	1	-P223130
033	051-33160-20	1	
034	066-32300-20	1	-P223130
035	725-32600-20	1	-P223130
035	765-32120-20	1	P223131-
036	990-72045-164	6	
048	925-33160-20	1	

H02-08 THT-210 GEAR CASE / BLADE



REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
001	300-33160-80	1	
002	993-50014-002	1	-M164900
002	993-50015-002	1	M164901-
003	999-61600-200	1	
004	999-61600-202	1	
005	288-33160-80	1	-M164900
005	288-33180-80	1	M164901-
006	305-33160-20	1	
007	075-33160-20	1	
008	101-33160-22	2	
009	307-33160-20	1	-M164900
009	307-33180-20	1	M164901-
010	303-33160-20	1	
011	630-33160-20	1	
012	122-33160-20	1	-N068730
012	122-33168-20	1	N068731-
013	136-33160-20	1	P223131-
014	990-52060-165	2	
015	120-33160-20	2	-N068730
015	120-33168-20	2	N068731-
016	085-33160-20	2	
017	129-33202-20	4	-N068730
017	129-33202-20	5	N068731-
018	124-33202-21	5	
019	123-33202-20	4	-N068730
019	123-33202-20	5	N068731-
020	992-10040-062	8	
021	990-51040-103	8	
022	300-32250-80	1	
023	990-51060-143	2	
067	198-11600-80	1	
069	138-33160-20	1	-N068780
069	138-33165-20	1	-P223130
069	138-33171-20	1	P223131-
071	992-10060-012	2	
072	991-01060-011	2	
081	992-01060-011	3	P223131-