


H04


***Tanaka***

**THT-240**

Serial No. - R278100




REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
001	157-06500-91	1	
002	018-11660-21	1	
003	002-06500-20	1	
004	990-11050-201	2	
005	992-10050-012	2	
006	992-00050-011	2	
007	017-06500-20	1	
008	041-00601-21	1	
009	031-06500-20	1	
010	037-06500-20	1	
011	039-01620-20	2	
012	046-06500-80	1	
013	999-62081-225	1	
027	153-21532-90	1	
028	994-16040-226	2	
036	250-06500-20	1	
037	178-06500-80	1	R078201-
038	167-21532-80	1	R078201-

**H04-02****THT-240 CRANK CASE**


REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
021	072-06500-90	1	
022	090-06500-20	1	
023	999-66122-269	2	
024	999-61600-100	2	
025	330-00200-21	V	
025	330-00200-22	V	
025	330-00200-23	V	
025	330-00200-24	V	
026	599-00601-20	1	
029	992-10050-012	3	
030	990-11050-301	3	
031	155-21523-80	1	
032	992-01080-011	1	
033	992-10080-012	1	
034	991-01080-011	1	
035	100-02100-20	2	

# H04-03

# THT-240 ENGINE-1




REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
025	403-06500-20	1	
026	404-06500-80	1	
027	994-16050-252	2	
030	402-06500-20	1	
033	999-67015-000	1	
035	423-06500-80	1	
036	470-06500-20	2	
037	528-0650T-20	1	
038	992-04080-031	1	
039	476-01700-20	1	
040	992-10050-012	2	
041	990-11050-602	2	
043	446-06500-20	1	
044	452-06500-20	1	
045	380-0637C-20	1	
050	700-53005-11	1	-P003585
050-1	700-53005-13	1	P003586-
050-1	700-53005-13	1	-R078200
050	223-06500-90	1	R078201-
051	680-00731-20	1	
052	675-0641E-90	1	-P003585
052	675-04042-80	1	P003586-
053-1	591-06500-20	1	-R078200
053	591-06500-21	1	R078201-
055	659-00801-20	2	
058	994-63050-185	2	
063	595-0650R-90	1	
086	626-32810-20	1	

**H04-04****THT-240 ENGINE-2**


REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
003	738-06500-20	1	
004	737-06500-20	1	
005	133-06500-20	1	
006	706-06500-80	1	
007	992-01050-011	2	
008	990-51050-503	2	
011	112-06500-80	1	
012	780-06097-20	1	
013	774-06097-20	1	
014	801-06091-20	1	
015	839-00025-20	1	
016	798-06500-90	1	
017	203-0604A-20	1	
018	783-06097-20	1	
019	785-06410-20	1	
020	994-15040-162	3	
021	751-06500-20	1	
022	721-06504-80	1	
023	992-10040-012	2	
024	990-11040-081	2	
047	277-0634F-90	1	
061	990-72045-164	1	
062	994-25040-128	2	
065	790-06097-20	1	
066	788-06500-20	1	

# H04-05


# THT-240 CARBURETOR




REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
000	455-25145-90	1	
001	548-25140-20	2	
005	539-25120-20	1	
007	489-25100-20	1	
008	488-25145-80	1	
010	550-25100-20	1	
011	599-2000W-41	1	
013	577-25100-20	1	
014	576-25100-20	1	
015	523-25100-20	1	
016	522-25100-20	1	
017	578-25007-20	1	
018	575-25140-80	1	
019	475-25001-20	1	
020	474-25001-80	1	
021	476-25004-20	1	
022	548-25101-20	4	



REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
001	300-3318B-80	1	
002	993-50015-002	1	
003	999-61600-200	1	
004	999-61600-202	1	
005	288-33180-80	1	
006	305-33160-20	1	
007	075-33160-20	1	
008	101-33160-21	2	
009	307-33180-20	1	
010	303-33160-20	1	
011	630-33160-20	1	
012	122-33180-20	1	
013	136-3318B-20	1	P230381-
014	990-52060-165	2	
016	085-33160-20	2	
017	121-33180-20	1	
018	120-33180-20	1	
022	300-32250-80	1	
023	990-51060-143	2	
024	129-33202-20	5	
025	124-33202-21	4	
039	125-33202-20	1	
040-1	051-33210-82	1	-P230380
040	051-3318B-80	1	P230381-
041	165-33130-20	1	
042	123-33202-20	5	
043	992-10060-012	5	-P230380
043	992-01060-011	4	P230381-
044	992-01060-011	1	
049-1	138-33215-20	1	-P230380
049	138-3318B-21	1	P230381-
071	992-10060-012	2	
072	991-01060-011	2	


**H04-07****THT-240 HANDLE BRACKET**

SEE H04-06



REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
020	992-10040-062	8	-P054210
020	992-10040-062	6	P054211-
021	990-51040-103	8	-P054210
021	990-51040-103	6	P054211-
026	994-61040-105	2	P054211-
033	990-51050-353	2	
035	057-33234-20	1	
036	060-33250-20	2	
037	058-33180-80	1	
038	176-33410-20	1	
057	994-61050-125	2	
058	992-10050-012	2	-P054210



**H04-08****THT-240 HANDLE**

REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
001	053-33231-22	1	
002	054-33231-22	1	
003	230-33210-20	1	
004	231-33210-20	1	
005	061-32600-20	1	
006	170-33180-80	1	
007	925-32530-20	1	
008	319-37900-20	1	
010	725-32600-20	1	-P230380
010	765-32120-20	1	P230381-
011	064-33225-20	1	-P230380
012	066-32300-20	1	-P230380
013	990-11040-301	2	
014	990-11040-251	1	
015	055-33250-90	1	-P230380
015	055-3318B-90	1	P230381-
016	050-33180-80	1	
017	885-0650J-80	1	
018	164-07016-50	1	
019	990-11040-141	3	
020	992-10040-012	6	
021	992-00040-011	6	
022	991-78040-010	6	
023	994-31030-101	1	
024	258-11650-20	1	
025	198-33130-20	1	